HCPCS:

| PRODUCTS | Description |
|---|---|
| LDR410011L | Left ArmrestAssembly,Titan,Intrepid,1/ea |
| LDR410011R | RightArmrestAssembly,Titan,Intrepid,1/ea |
| LDR410110 | Armrest Pad - Titan,Intrepid,1/ea |
| LRA402203-03 | Touch Control Panel-Pilot/Prowler/Osprey |
| LRA402204-03 | PC Board w/o Spd Dial,Pilt/Prwlr/OspryG2 |
| LRA402204-03SD | Speed Dial Assembly for LRA402204-03 |
| LRA402210 | 5A Battery Charger for POV |
| LRA402210-02 | Charge Port - Pilot/Prowler/Osprey |
| LRA402210-03 | Charge Port - Generation 2 Pilot/Prowler |
| LRA402225-01 | Rear Mirror - Left |
| LRA402226 | Front Basket - Pilot/Prowler/Osprey |
| LRA402317 | Seat Slides - Pilot/Prowler/Osprey,1/set |
| LRB402300-15 | Negative Battery Harness - Prowler, 1/ea |
| LRB402300-16 | Positive Battery Harness - Prowler, 1/ea |
| LRB402348 | TillerBearingSetProwler,1ea |
| LRC402307/LRB | 70 Amp Circuit Breaker |
| LRC402414 | Seat Bracket - Captain Seat |
| LRC402414-13 | Seat Post - Captain Seat |
| LRM402200-21 | Horn for Pilot, Prowler, & Osprey, 1/ea |
| LRM412101-08 | Basket Bracket - Spitfire/Pilot/Prowler/ |
| LRM412103-11 | Speed Control Knob |
| ST301-201820 | 20" Captain Seat |
| ST301-201820-S | 20" Captain Seat Assembly - Scooter |
| ST306-222020 | 22" Captain Seat |
| ST306-222020-S | 22" Captain Seat Assembly - Scooter |
| STDS2A5303 | 24"Wheel Bearing,SentraXW,1/ea |